



## **IMPORTANT - Read these instructions completely before installing the G-4 or G-5 SERIES Top & Base.**

Congratulations on your purchase of a Nuance Grand Series speaker system. We are very proud of its attractively styled and finished enclosure. In order to maintain a perfect finish, we have shipped this top and base to you in special packaging designed to keep the surfaces free from any pressure of the packaging and to ensure no smudges or scratches occur in shipment. Please follow these instructions to avoid damage while installing them.

### **1. Unpacking the top and base.**

Remove the foam corner pads and lift out the inner carton. Place it flat on a carpeted floor with the edges that have the most staples down. With scissors or a knife, carefully slit open the tape along the sides of the sleeve separating the top and bottom covers (trays). Lift up the cardboard tray containing the base and place it carefully on a soft carpeted surface with the cardboard side up so that the screws and washers are visible. Remove the screws. Lift off the cardboard cover. Repeat for the other side, removing the screws and when complete, lift off the cardboard cover.

### **2. Installing the Base.**

Please note that the base is the larger item with the large hole in the center and (4) mounting holes which go through both sides, and (4) holes which contain metal inserts and are threaded to accept the sharp 1" conical supports and sit on the floor.

On a soft carpeted surface, carefully lie down your Nuance GRAND SERIES speaker on its (wide) side with a pillow or the foam packaging end-piece placed near both ends in the approximate spot you want to locate them for listening. At the speaker bottom where the terminal connections are visible, carefully line up the (4) through holes in the base with the (4) threaded inserts in the speaker bottom and insert (2) of the 2" screws and screw (3 or 4 turns) them part way into the base on opposite, diagonal corners. Now insert and screw in the other 2 screws. Continue tightening all (4) screws until fully in. Do not overtighten.

Next, using a clean rag or paper towel, carefully wipe any excess oil from the (4) conical metal feet and screw them into the (4) outside holes of the base which contain the threaded metal inserts.

### **3. Installing the Top.**

With clean hands, pickup the top from the floor and place it carefully on the speaker so that the 4 dowel pins are inserted into the rubber receptacles. Press the Top firmly to the cabinet (*pins*).

After connecting your speaker wiring to the amplifier/receiver, carefully raise your speaker while making sure that the edge of the base does not rub against the floor or damage your speaker cable. This can be done by pushing the pillow or other support right to the end of the speaker cabinet.

*Note: To clean your Top and Base, only use cheesecloth or similar lint-free soft cloth and rub lightly. If they develop scratches, you can remove the scratches by polishing the surface with a fine furniture-grade rubbing compound and cheesecloth or a high-quality, non-abrasive car wax.*