



IMPORTANT - Read these instructions completely before installing the G-6 SERIES Top and Base.

Congratulations on your purchase of a Nuance Grand Series speaker system. We are very proud of its attractively styled and finished enclosure. In order to maintain a perfect finish, we have shipped these tops and bases to you in special packaging designed to keep the surfaces free from any pressure of the packaging to ensure no smudges or scratches in shipment. Please follow these instructions to avoid marking your top or base while installing them.

1. Unpacking the top and base.

Remove the foam corner pads and lift out the inner carton. Place it flat on the floor with the edges that have the most staples down. With scissors or a knife, carefully slit open the tape along the sides of the sleeves between the top and bottom covers (trays). Lift up the cardboard tray containing the base and place it carefully on a soft carpeted surface with the cardboard side up so that the screws and washers are visible. Remove the screws. Lift off the cardboard cover. Repeat for the other side, removing the screws and when complete, lift off the cardboard cover.

2. Installing the Base.

Please note that the base is the item with (8) mounting holes which go through both sides, and (4) holes which contain metal inserts and are threaded to accept the sharp 1" conical supports which sit on the floor.

On a soft carpeted surface, carefully turn your Nuance GRAND SUB R S speaker upside down so that the terminal connections are visible. Take (2) of the 1" screws which you have removed in step 1 above, and screw (3 or 4 turns) part way into the base on opposite, diagonal corners. (*These screws allow you to grip the base without touching it.*) Using these screws, lift up the base and place on the speaker. Line up the (8) holes in the base with those in the bottom of the speaker cabinet. Fasten the base to the cabinet using the 2" screws provided (*in the polybag*).

Next, using a clean rag or paper towel, carefully wipe any excess oil from the (4) conical metal feet and screw them into the (4) outside holes of the base which contain the threaded metal inserts.

3. Installing the Top.

After connecting your speaker wiring to the amplifier/receiver, carefully turn your speaker over ready for installation of the Top. With clean hands, pick up the top from the floor and place carefully on the speaker so that the 4 dowel pins are inserted into the rubber receptacles. Press the Top down firmly to the cabinet (*pins*).

Note: To clean your Top and Base, only use cheesecloth or similar lint-free soft cloth and rub lightly. If they develop scratches, you can remove the scratches by polishing the surface with a fine furniture-grade rubbing compound and cheesecloth.